

FLECK 2510 AIR INJECTION OXIDIZER (AIO) VALVE



Fleck 2510 Control Valve



WHAT IS AIO?

Utilizes an air injection system to remove iron (ferrous or clear water), manganese, and sulfur from the water via both oxidation and filtration.

FEATURES • BENEFITS

- Fully assembled and programmed AIO control setting for easy installation
- No chemical additives or air compressors are required for operation
- Robust, proven brass piston able to withstand demanding needs of the application

REDUCES



Manganese

AVAILABLE ON

Pentair Fleck 2510 Control Valve

FREQUENTLY ASKED QUESTIONS

Q: Does a system with the Fleck AIO Valve get installed before or after the softener?

A: The system with the Fleck AIO Valve should be installed before the softener. This ensures the softener and other filter systems are protected by filtering contaminants before the water goes into the softener to be softened.

Q: What control meters are compatible with the Fleck AlO Valve?

A: The Fleck AIO Valve is available with the Fleck SXT controller only.

Q: How do systems with the Fleck AIO Valve treat iron, manganese, and sulfide?

A: The valve utilizes an air injection system to remove iron (ferrous or clear water), manganese, and sulfur from the water via both oxidation and filtration.

Q: What is oxidization?

A: Oxidation is the loss of electrons during a reaction by a molecule, atom, or ion. In this process a substance is changed because of the addition of oxygen. When an iron object is oxidized, it goes from a strong metal to a red powder.

Q: Are chemicals necessary to reduce contaminants when the Fleck AIO Valve is used?

A: No, because it is using the oxidation process to remove contaminants (oxidation).

